Microblasting Equipment PEENMATIC 950 ZIDA







- Standard equipment: This automatically working microblasting equipment is provided with an automatically controlled rotary table unit, Ø 800 mm, for the transport of flat small parts through the microblasting equipment. The parts will be microblasted from above with 3 horizontal / radial movable microblasting pistols. Small and mass production parts can be cleaned, deburred, structured and densificated (silk matt polished) in a fast and efficient way
 - Blowing-off device, allowing to take out workpieces almost dustless
 - Special front flap door which is operated with cylinders actuated by compressed gas, with integrated sight window, provided with a safety glass and an attrition-proof glass in a quick change frame
 - Microblasting pistol units, type EF-A 4, complete, with hard metal blasting nozzle HSD 8/15, adjustable via pressure reducing valve, 0 - 8,5 bar, microblasting pressure reading on the manometer
 - Microblasting agent pre-accelerating system with moving injector, adjustable via pressure reducing valve, 0 - 4 bar, pressure reading on the manometer
 - Automatic, selective recycling of microblasting agent by high-performance cyclone
 - Microblasting agent tank, installed at the back right, designed for 3 moving injectors
 - Drying system for microblasting agents
 - Microblasting agent level monitoring with by means of a sensor
 - Key-operated switch, on / off, with 2 keys
 - Built-in high-surface microfilter system, containing two filter cartridges with 2 m2 surface each. Automatic pneumatic filter cleaning with time intervals
 - Dust collector, made of steel

Sales / Development iepco ag Hofstrasse 21 CH-8181 Höri Phone +41 / (0)44 861 16 16 +41 / (0)44 860 63 86 Fax www.iepco.ch


Production Plant iepco ag Steiächerweg 10 CH-5316 Leuggern Phone +41 / (0)56 268 80 40 +41 / (0)56 268 80 50 Fax info@iepco.ch

Technologies for perfect surfaces

Publ.No. PM 950 ZIDA Page 1 of 2 Date 08/2007

Microblasting Equipment PEENMATIC 950 ZIDA





info@iepco.ch

www.iepco.ch